

Normal Power Down of the AS400:

1. Clear all activity on the System 36 (Console Messages, D_U, D_I, D_P, D_J) then from FAX250 type POWER OFF on the command line to shut down the System36.
2. Jump to the AS400 Console and on the AS400 Main Menu, type GO MESSAGE and check that all console messages are cleared, then command 3 back to the AS400 Main Menu.
3. On the AS400 Main Menu, type GO POWER and press the enter key.
4. On the “Power On and Off Tasks” screen, select option 3 to “Power off the system immediately,” and press the enter key.
5. To confirm that you want to power off, press the CMD16 key.
6. The AS400 should do an immediate power down.

Is the AS400 “Hung Up”? Follow these instructions to force a Power Down:

1. Open the door on the front of the AS400 CPU.
2. Press the up arrow button once and “02” should show in the display. (Press the up arrow button several times and cycle to “02” if “02” doesn’t appear by pressing the up arrow button just one time.)
3. Press the blue “enter” button. “BN” will reappear so now the display shows “02 BN”.
4. Press the up or down arrow button until “02 BM” shows in the display.
5. Press the blue “enter” button and just the “02” will show in the display.
6. Press the down arrow button once and “01” will be displayed.
7. Press the blue “enter” button again and “01 BM” will be displayed.
8. With “01 BM” displayed, press the white power button and a flashing questionmark should appear in the display.
9. Press the white power button a second time and the AS400 should power off. As it powers down you will see D_____ (The capital letter “D”

followed by several numbers), in the Function/Data display. "01 BM" will be displayed when the power off is complete.

10. Reset the display from "01 BM" to "01 BN" by pressing the up arrow button one time so that "02" is displayed.
11. Press the "enter" button, then press the up or down arrow button until "02 BN" is displayed.
12. Press the "enter" button, then press the down arrow button one time to display "01", then press the "enter" button to display "01 BN".
13. Press the white power button to power the AS400 back on. (Refer to the following instructions regarding starting the AS400.)

Starting the AS400:

1. Make sure "01 BN" shows on the AS400 CPU display.
2. Be sure all IBM printers are turned on.
3. Press the white button on the front of the AS400 CPU to start it IPLing.
4. The AS400 Main Menu will appear on side one of your split screen console after a few minutes.
5. Now jump to side two of your split screen console and after a few more minutes the AS400 signon screen will go away, the screen will be blank, then the System 36 signon screen will appear.
6. After the System 36 is started, jump back to the AS400 console signon screen (side one), and type `GO PRINTER` and set the printer status' to "END" to pass control of the printers to the System36.